

# Strobe Light Instructions

## CARE AND OPERATION

PLEASE READ ALL OF THE INSTRUCTIONS BEFORE OPERATING.

**WARNING:** Strobe lights should not be used by people who are prone to flicker-sensitive Epilepsy. If this unit is used with the general public present, be sure to angle the strobe light away from people's gaze and set the variable flicker rate to half speed or less to ensure the light does not flash faster than 4 flickers per second. When using this product basic safety precautions should always be followed as outlined below:

### IMPORTANT SAFETY INSTRUCTIONS:

1. This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet one way. If the gig does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted. Do not alter the plug in any way. Only use an extension of the same size as the original wire.
2. Always unplug this product when not in use.
3. Do not place or store this product where it can fall or be pulled into water. Do not submerge in liquid of any kind.
4. Do not allow liquid of any kind to get into the unit.
5. Do not use outdoors.
6. Clean only with a dry, soft cloth. **USE NO LIQUIDS!**
7. Keep unit and cord out of reach of small children and pets.

## WARNING — To reduce the risk of fire or injury:

1. Never operate unit :
  - If it has a damaged cord or plug.
  - If it not working properly.
  - If it has been dropped, damaged, or immersed in water.
2. Keep the cord away from heated surfaces.
3. Never block the air opening of the unit.
4. Never place it near fabrics or combustible materials.
5. Never drop or insert any object into any opening.
6. Unplug this product before replacing the right bulb.
7. Always unplug this product immediately after using.
8. Do not operate the unit for more than 10 hours at a time.
9. Do not attempt to force the polarized plug into an outlet.

### OPERATING INSTRUCTIONS:

1. Carefully unpack and place the unit on a level surface.
2. Plug the strobe light into the wall.
3. Turn the strobe light on by turning the on/off speed control knob to the right.
4. You can adjust the frequency of the strobe light flashes by turning the speed control knob to the right or left.

**Power Rating:** 120V/ 60Hz/ 25W

**NOTE:** If you notice that the flash rate changes unexpectedly try to adjust it by turning the Speed Control Knob on the back of the unit.

If this does not change the flash rate then this is an indication that the bulb is about to fail.

But please note **THE BULB IS NON-REPLACEABLE! DO NOT TRY TO PULL THE BULB OUT.**

### MOUNTING INSTRUCTIONS:

1. Key hole slots for easy mounting.

### LIMITED 90 DAY WARRANTY

This unit is warranted by LAVA LITE LLC® against defects in workmanship or materials for 90 days from the date of purchase. The duration of any express or implied warranties, including implied warranties of merchantability or fitness for a particular purpose, are limited to 90 days from the date of purchase. This warranty shall be void if the lamp has been subject to abuse, negligent handling, disregard of operating instructions or attempted repair by anyone other than the manufacturer. LAVA LITE LLC® shall in no event be responsible for incidental or consequential damages of any nature or amount. NOTE: Some states do not allow limitations on how long an implied warranty lasts or do not allow the exclusion or limitation of consequential damages, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights and you (as a purchaser) may also have other rights which vary from state to state.

### SERVICE AND REPLACEMENT INSTRUCTIONS

**Within the 90 day warranty period**, if for any reason, other than a burned out light bulb or misuse (see Care and Instructions), your unit does not function properly, then **return it to your retailer**. The manufacturer is the only one that can make warranty replacements after 90 days. **DO NOT RETURN THE LAMP LAVA LITE LLC® UNLESS AUTHORIZED BY A COMPANY REPRESENTATIVE**. Customer Service may be contacted at 1-800-336-5282 or via e-mail at [infomaster@lavalite.com](mailto:infomaster@lavalite.com).

LAVA®, LAVA LITE® and the configuration of the LAVA LITE MOTION LAMP are registered trademarks of LAVA LITE, LLC® in the U.S.A. and in other countries around the world, ©2009 LAVA LITE, LLC. All rights reserved. Made in China.

**For a complete listing of all LAVA® brand products, please visit us at [www.lavalite.com](http://www.lavalite.com)**

**SAVE THESE INSTRUCTIONS.**



